Understanding clock domain crossing issues

By Saurabh Verma Engineering Manager Atrenta Ashima S. Dabare Consulting Applications Engineer Atrenta

Introduction

SoCs are becoming more complex these days. A lot of functionality is being added to chips and data is frequently transferred from one clock domain to another. Hence, clock domain crossing verification has become one of the major verification challenges in deep submicron designs.

A clock domain crossing occurs whenever data is transferred from a flop driven by one clock to a flop driven by another clock.

In Figure 1, signal A is launched by the C1 clock domain and needs to be captured properly by the C2 clock domain. Depending on the relationship between the two clocks, there could be different types of problems in transferring data from the source clock to the destination clock. Along with that, the solutions to those problems can also be different.

Traditional methods like simulation and static timing analysis alone are not sufficient to verify that the data is transferred consistently and reliably across clock domains. Hence, new verification methodologies are required, but before devising a new methodology it is important to understand the issues related to clock domain crossings properly. Different types of clock domain crossings are discussed here along with the possible issues encountered in each one of them and their solutions. A new verification methodology is then proposed which will ensure that data is transferred correctly across clock domains.

In all the subsequent sec-

tions, the signal names shown in Figure 1 are directly used. For example, C1 and C2 imply the source and destination clocks respectively. Similarly A and B are used as source and destination flop outputs respectively. Also, the source and destination flops are assumed to be positive edge triggered.


Clock Domain Crossing Issues This section describes three main issues, which can possibly occur whenever there is a clock domain crossing. The solutions for those issues are also described.


A. Metastability


Problem. If the transition on signal A happens very close to the active edge of clock C2, it could lead to setup or hold violation at the destination flop "FB". As a result, the output signal B may oscillate for an indefinite amount of time. Thus the output is unstable and may or may not settle down to some stable value before the next clock edge of C2 arrives. This phenomenon is known as metastability and the flop "FB" is said to have entered a metastable state.

Metastability in turn can have the following consequences from a design perspective:

- If the unstable data is fed to several other places in the design, it may lead to a high current flow and even chip burnout in the worst case.
- 2. Different fan-out cones may read different values of the signal, and may cause the design to enter into an unknown functional state, leading to functional issues in the design.
- 3. The destination domain output may settle down to the new value or may return to the old value. However, the propagation delay could be high leading to timing issues.







For example, see Figure 2. If the input signal A transitions very close to the posedge of clock C2, the output of the destination flop can be metastable. As a result it can be unstable and may finally settle to 1 or 0 as depicted by signals B1 and B2.

Solution. Metastability problems can be avoided by adding special structures known as synchronizers in the destination domain. The synchronizers allow sufficient time for the oscillations to settle down and ensure that a stable output is obtained in the destination domain. A commonly used synchronizer is a multi-flop synchronizer as shown in Figure 3.

This structure is mainly used for single and multi-bit control signals and single bit data signals in the design. Other types of synchronization schemes are required for multi-bit data signals such as MUX recirculation, handshake, and FIFO.

B. Data Loss

Problem. Whenever a new source data is generated, the destination

domain may not capture it in the very first cycle of the destination clock because of metastability. As long as each transition on the source signal is captured in the destination domain, data is not lost. In order to ensure this, the source data should remain stable for some minimum time, so that the setup and hold time requirements are met with respect to at least one active edge of destination clock.

If the active clock edges of C1 and C2 arrive close together, the first clock edge of C2, which comes after the transition on source data A, is not able to capture it. The second edge of clock C2 finally captures the data (Figure 4).

However, if there is sufficient time between the transition on data A and the active edge of clock C2, the data is captured in the destination domain in the first cycle of C2.

Hence, there may not be a cycle by cycle correspondence between the source and destination domain data. Whatever the case, it is important that each transition on the source data should get captured in the destination domain.

For example: Assume that the source clock C1 is twice as fast as the destination clock C2 and there is no phase difference between the two clocks. Further assume that the input data sequence "A" generated on the positive edge of clock C1 is "00110011". The data B captured on the positive edge of clock C2 will be "0101". Here, since all the transitions on signal A are captured by B, the data is not lost. This is depicted in Figure 5.

However, if the input sequence is "00101111", then the output in the destination domain will be "0011". Here the third data value in the input sequence which is "1" is lost as shown in Figure 6.

Solution. In order to prevent data loss, the data should be held constant in the source domain long enough to be properly captured in the destination domain. In other words, after every transition on source data, at least one destination clock edge should arrive where there is no setup or hold violation so that the source data is captured properly in the destination domain. There are several techniques to ensure this

For example, a finite state machine (FSM) can be used to generate source data at a rate. such that it is stable for at least 1 complete cycle of the destination clock. This can be generally useful for synchronous clocks when their frequencies are known. For asynchronous clock domain crossings, techniques like handshake and FIFO are more suitable.


C. Data Incoherency

Problem. As seen in the previous section whenever new data is generated in the source clock domain, it may take 1 or more destination clock cycles to capture it, depending on the arrival time of active clock edges. Consider a case where multiple signals are being transferred from one clock domain to another and each signal is synchronized separately using a multi-flop synchronizer. If all the signals are changing simultaneously and the source and destination clock edges arrive close together, some of the signals may get captured in the destination domain in the first clock cycle while some others may be captured in the second clock cycle by virtue of metastability. This may result in an invalid combination of values on the signals at the destination side. Data coherency is said to have been lost in such a case.


If these signals are together controlling some function of the design, then this invalid state may lead to functional errors.

For example: Assume that "00" and "11" are two valid values for a signal X[0:1] generated by clock C1. As shown in Figure 7, initially there is a transition from 1->0 on both the bits of X. Clock C2 captures both the transitions in the first cycle itself. Hence the signal Y[0:1] becomes "00".

Next, there is a transition from








No data is lost in this case.

5.




0->1 on both the bits of signal X. Here the rising edge of clock C2 comes close to the transition on signal X. While the transition on X[0] is captured in the first clock cvcle, the transition on X[1] gets captured in second clock cycle of C2. This results in an intermediate value of "10" on Y[0:1] which is an invalid state. Data coherency is lost in this case.

Solution. In the above example, the problem results because all the bits are not changing to a new state in the same cycle of destination clock. If all the bits either retain their original value or change to the new value in the same cycle, then the design either remains in the original state or goes to a correct new state


Now, if the circuit is designed in such a way that while changing the design from one state to another, only one bit change is required, then either that bit would change to a new value or would retain the original value. Since all the other bits have the same value in both the states, the complete bus will either change to the new value or retain the original value in this case.

This in turn implies that if the bus is Gray-encoded, the problem would get resolved and an invalid state would never be obtained.


However, this is applicable only for control busses as it may not be possible to Grayencode the data busses. In such cases, other techniques like handshake, FIFO and MUX recirculation can be used to generate a common control logic to transfer data correctly. The MUX recirculation technique is shown in Figure 8.



7. Data coherency is lost in this case.



8. MUX recirculation technique.





Here, a control signal EN, generated in the source domain is synchronized in the destination domain using a multi-flop synchronizer. The synchronized control signal EN_Sync drives the select pin of the muxes, thereby controlling the data transfer for all bits of the bus A. In this way, individual bits of the bus are not synchronized separately, and hence there is no data incoherency. However, it is important to ensure that when the control signal is active, the source domain data A[0:1] should be held constant.

Synchronous Clock Domain Crossings

This section describes various types of synchronous clock domain crossings. Clocks, which have a known phase and frequency relationship between them, are known as synchronous clocks. These are essentially the clocks originating from the same clock-root. A clock crossing between such clocks is known as a synchronous clock domain crossing. It can be divided into several categories based on the phase and frequency relationship of the source and destination clocks as follows:

- Clocks with the same frequency and zero phase difference
- Clocks with the same frequency and constant phase difference
- Clocks with different frequency and variable phase difference
- Integer multiple clocks
- Rational multiple clocks

All the above sub categories may not be used in real designs but are being considered here for completeness and better understanding of the subject.

While describing all the above cases, it is assumed that the source clock (C1) and the destination clock (C2) have the same phase and frequency jitter and are balanced with the same specifications of clock latency and skew. It is also assumed that the clocks begin with a zero phase difference between them and the "clock to Q" delay of the flops is 0.

Clocks with the same frequency and zero phase difference This refers to two identical clocks, as the clocks C1 and C2 have the same frequency and 0 phase difference. Note, that as the clocks C1 and C2 are identical and generated from the same root clock, the data transfer from C1 to C2 is essentially not a clock domain crossing. For all practical purposes, this is the case of a single clock design and is considered here for completeness.

Whenever data is transferred from clock C1 to C2, one complete clock cycle of C1 (or C2) is available for data capture as shown in Figure 9.

As long as the combinational

logic delay between the source and destination flops is such that the setup and hold time of the circuit can be met, the data will be transferred correctly. The only requirement here is that the design should be STA (static timing analysis) clean. In that case, there will be no problem of metastability, data loss or data incoherency.

Clocks with the same frequency and constant phase difference These are the clocks having the same time period but a constant phase difference. A typical example is the use of a clock and its inverted clock. Another example is a clock which is phase shifted from its parent clock, for example by T/4 where T is the time period of the clocks.

Clocks C1 and C2 have the same frequency but are phase shifted and C1 is leading C2 by 3T/4 time units (Figure 10).

Whenever data is transferred from clock C1 to C2, there is more restriction on the combinational logic delay due to smaller setup/hold margins. If the logic delay at the crossing is such that the setup and hold time requirements can be met, data will be transferred properly and there will be no metastability. In all such cases, there is no need for a synchronizer. The only requirement here is that the design should be STA clean.

Clocks with different frequency and variable phase difference These are clocks that have a different frequency and a variable phase difference. There can be two sub-categories here, one where the time period of one clock is an integer multiple of the other and a second where the time period of one clock is a non-integer (rational) multiple of the other. In both cases, the phase difference between the active edges of clocks is variable. These two cases are described in detail below.

A. Integer multiple clocks

In this case, the frequency of one clock is an integer multiple of the other and the phase difference between their active edges is variable. Here the minimum possible phase difference between the active edges of 2 clocks would always be equal to the time period of the fast clock.

In Figure 11 clock C1 is 3 times faster than clock C2. Assuming T is the time period of clock C1, the time available for data capture by clock C2 could be T, 2T or 3T depending on which edge of clock C1 the data is launched. Hence, the worst case delay of any path should meet the setup time with respect to the edge with a phase difference of T. The worst case hold check would be made with respect to the edge with 0 phase difference.

In all such cases, one complete cycle of the faster clock is always available for data capture, hence it should always be pos 8. Clocks with the same frequency and phase. 8. Clocks with the same frequency and phase. sible to meet the setup and hold requirements. As a result there will be no metastability or data incoherency and a synchronizer is not needed.

However, there can still be a problem of data loss in the case of fast to slow clock crossing. (That is, the source clock is faster than the destination clock.) In order to prevent this, the source data should be held constant for at least one cycle of the destination clock. Using some control circuit can ensure this, for example, a simple finite state machine (FSM) would work in this case. In the example shown in Figure 11, if the source data is generated once in every 3 cycles of the source clock, there would be no data loss. For the case of slow to fast crossings, there will anyways be no data loss.

B. Rational multiple clocks

In this case, the frequency of one clock is a rational or non-integer multiple of the other clock and the phase difference between the active clock edges is variable.

Unlike the situation where one clock is an integer multiple of the other, here the minimum phase difference between the two clocks can be very small- small enough to cause metastability. Whether or not a metastability problem will occur depends on the value of the rational multiple, and the design technology. Three different cases are being considered here with the help of examples.

In the first case, there is a sufficient phase difference between the active edges of the source and destination clocks such that there will be no metastability.

In the second case, the active clock edges of the two clocks can come very close together, close enough to cause metastability problem. However, in this case the frequency multiple is such that, once the clock edges come close together, there would be sufficient margin in the next cycle to capture data properly without any setup or hold violation.

In the third case, the clock edges of the two clocks can be close enough for many consecutive cycles. This is similar to the behaviour of asynchronous clocks except that here the clock-root for both the clocks is the same and hence the phase difference between the clocks can be calculated.

Note that in all the examples given below, some delay values are used and it is assumed that a phase margin of less than or equal to 1.5ns between the clock edges can cause metastability. This is just a placeholder value and in real designs, it would be a function of many things including technology used, flop characteristics, etc.

Example 1

This is the case when the active clock edges of both the clocks will never come very close together, and in all cases there would be a sufficient margin to meet the setup and hold requirements of the circuit.

Consider a clock C from which 2 clocks C1 and C2 are derived with a frequency of divide-by-3 and divide-by-2 respectively with respect to clock C. Here clock C1 is 1.5 times slower than




Figure 9. Same frequency, phase shifted clocks.




Figure 11. Integer multiple clocks.




Figure 11. Clock edges never come very close together.

clock C2. As shown in Figure 12, the time period of clock C1 is 15ns and of C2 is 10ns. The least possible phase difference between the two clock edges is 2.5ns, which should be sufficient to meet setup and hold time requirements.

However, additional combinational logic should not be added at the crossing due to the very small setup/hold margins. If there is any logic, its delay should meet the setup and hold time requirements. If this condition can be met, there will be no metastability and no synchronizer would be required.

Further, if the crossing is a slow to fast crossing, there will be no data loss. However, in case of a fast to slow clock crossing, there can be data loss. In order to prevent this, the source data needs to be held constant for at least one cycle of the destination clock so that at least one active edge of the destination clock arrives between two consecutive transitions on the source data.

Example 2

In this case, the active clock edges of both the clocks can come very close together intermittently. In other words, the clock edges come close together once and then there would be sufficient margin between the edges for the next few cycles (to capture data properly) before they come close again. Here the word "close" implies close enough to cause metastability.

In Figure 13, clocks C1 and C2 have time periods 10ns and 7ns respectively. Notice, that the minimum phase difference between the two clocks is 0.5ns, which is very small. So, there are chances of metastability and a synchronizer would be required.

Due to metastability, the data may not be captured in the des-

tination domain when the clock edges are very close together. However, in this case, note that once the clock edges come very close together, in the next cycle there is a sufficient margin so that the destination clock can capture the data properly. This is shown by signal B2 in Figure 13. While the expected output would be B1, the actual waveform could look like B2, but still there is no data loss in this case. However there can be an issue of data incoherency as described previously.

For a fast to slow crossing, data loss can occur, and in order to prevent this, the source data should be held constant for a minimum of one destination clock cycle. Again, this can be done by the use of a simple FSM.

Example 3

This is the case when the phase difference between the clocks can be very small at times and can remain like that for several cycles. This is very similar to asynchronous clocks except that the variable phase differences will be known and will repeat periodically.

In Figure 14, clocks C1 and C2 have time periods 10ns and 9ns respectively. It can be seen that the active clock edges of both the clocks come very close together for 4 consecutive cycles. In the first two cycles there is a possibility of a setup violation (as the source clock is leading the destination clock) and in the next two cycles there is a possibility of hold violation (as the destination clock is leading the source clock).

In this case, there will be an issue of metastability and hence synchronization needs to be done. Apart from metastability there can be an issue of data loss also, even though it is a slow to fast clock domain crossing. As can be seen from Figure 14, B1 is the expected output if there would have been no metastability. However, the actual output can be B2. Here the data value '1' is lost, because in the first cycle

the value '1' is not captured due to setup violation and in the second cycle the new value '0' is incorrectly captured due to hold violation.

In order to prevent data loss, the data needs to be held constant for a minimum of two cycles of the destination clock. This is applicable for both fast to slow as well as slow to fast clock domain crossings. It can be done by controlling the source data generation using a simple FSM. However, the data incoherency issue can still be there.

In such cases, standard techniques like handshake and FIFO are more useful to control data transfer as they will also take care of the data incoherency issue.

Asynchronous Clock Domain Crossings


Clocks that do not have a known phase or frequency relationship between them are known as asynchronous clocks. Whenever there is a clock crossing between two asynchronous clocks, their active edges can arrive very close together leading to metastability. Here the phase difference between the clocks can be variable and unlike synchronous clocks it is unpredictable.

Proper synchronization needs to be done in the destination domain to prevent metastability. Apart from that, there can be problems of data loss and data incoherency (in both fast to slow as well as slow to fast clock crossings). If the source and destination clock frequencies are known, holding the source data constant for two cycles of the destination clock can prevent data loss. However, if the circuit is to be designed to be independent of clock frequencies, handshake or FIFO techniques should be used to prevent metastability, data loss and data incoherency.

Verification Methodology

This section describes a methodology that will ensure that the circuit has been designed properly to handle the clock domain crossing issues.

The validation activity can








Figure 14. Clock edges are close for consecutive cycles.

be divided into two categories, namely structural and functional. Structural validation ensures that appropriate synchronization logic has been added wherever it is required and functional validation ensures that the logic that has been added is actually performing the intended function.

A number of CDC problems can be detected just by performing structural validation. These checks are simpler and much faster than the functional validation. Moreover, if there are structural issues, most of the functional validation would have no relevance anyway. Hence, verification should begin with the structural checks and the problems detected there should be corrected before moving on to functional validation.

Rule-based checking is a very efficient way to perform structural validation. Assertion-based verification techniques can be used to perform functional validation. Assertions can be inferred automatically in the design using some EDA tools, or they can be inserted in the RTL using any of the standard assertion languages like OVL, PSL and SVA. Many EDA vendors support these languages.

These assertions can either be simulated in the functional simulation environment or can be verified using formal verification techniques. Both these techniques have their own advantages and disadvantages.

The simulation results are dependent on the quality of test vectors used. A problem may go undetected if the vectors applied cannot stimulate it, and it is very difficult to determine the right set of test vectors that will give good coverage.

As compared to simulation, formal techniques give a much better coverage and there is

no need to provide any test vectors. However, formal techniques have some performance issues because of state space explosion, which is a well known problem in formal analysis (see reference 4). So, these checks are not suitable for full chip analysis but they work reasonably well at the block level.

A step-by-step approach for verifying clock domain crossings is described here.

Step 1

Check for the presence of valid synchronizers in: All asynchronous clock domain crossings, and, those cases of synchronous clock domain crossings where there can be metastability as described in the section on rational multiple clocks.

A multi-flop synchronizer is sufficient to ensure that there will be no metastability. However, there can still be a problem of data incoherency. So, it is advisable to check at this stage only, that multi-flop synchronizers are used only for scalar signals. They can also be used for control busses. They should not be used for data busses however.

A rule-based checker can be used to automatically detect all clock domain crossings and to check for the presence of valid synchronizers at all places where they are required.

If there are missing synchronizers, the designer should modify the design to add appropriate synchronization logic.

Step 2

Check for the presence of separately synchronized signals that are converging. These are probable candidates for data incoherency. Doing structural analysis of the design can identify these candidates.

The candidate signals for data incoherence should be verified to be Gray-encoded. This validation can be done through assertions. A structural checking tool could even generate the assertion itself whenever it sees signals, which are candidates for data




Figure 15. Formal verification helps catch gray-encoding failure.

incoherency. Figure 15 shows a control bus clock domain crossing, which is synchronized using a multi-flop synchronizer but is not Gray-encoded. A waveform trace is generated for the assertion failure.

In case the converging signals cannot be Gray-encoded, change the synchronization scheme to one which uses a common control signal, for example, MUX recirculation, FIFO or handshake. These schemes still need to be validated for proper functionality as described in Step 4.

Step 3

Once the proper synchronization logic is in place and the Gray-encoding checks have been done, the next step is to verify that there is no data loss while transferring data from one clock domain to the other. This needs to be checked for the following two cases:

- Synchronous clock domain crossings
- All fast to slow crossings
- Slow to fast crossings where the clock edges can be close together for continuous cycles
 - All asynchronous clock domain crossings

Asserting that each source data launch is always captured in the destination domain can validate these.

In the case of fast to slow synchronous clock domain crossings, where a synchronizer is not required and for the simple cases of multi-flop synchronization, check that after every transition on the source data an active edge of the destination clock arrives where there is no setup or hold violation.

For other synchronization schemes, some standard functional checks can be done to ensure that there is no data loss, which are described in Step 4.

Step 4

In all cases, where some special synchronization schemes are used, it is necessary to verify that they are performing the intended function correctly. This is important to ensure that there will be no metastability, data incoherency or data loss problem.

The required checks are given here for three commonly used schemes:

- Handshake synchronization: Check that the request-data and request-acknowledge protocols are working as per the specifications.
- FIFO synchronization: Check


that there is no FIFO overflow or underflow.

- Mux recirculation: With reference to Figure 8, check that while the synchronized control signal EN_Sync is active, the following two conditions hold:
- o Source data A[0:1] is stable, and,
- o at least one active edge of destination clock arrives

The methodology described in the above four steps is also depicted in Figure 16.

Summary

Traditional verification methods like simulation and static timing analysis are not sufficient to detect all types of problems, which can occur in clock domain crossings. The problems that can occur depend on the types of clock domain crossings. Similarly, the solutions to those problems are also different and hence the verification techniques required are different as well. Some of the basic problems of clock domain crossings have been discussed here. The solutions to those issues are also discussed and a verification methodology is proposed which will ensure that data is correctly transferred across clock domains.



References

- [1] Sanjay Churiwala, "Tackling multiple clocks in SoCs", EE Times March 15, 2004.
- [2] Shaker Sarwary, "Solving the toughest problems in CDC analysis", EE Times August 28, 2006.
- [3] http://www.asic-world.com/ tidbits/metastablity.htm
- [4]K. McMillan, Symbolic Model Checking, Kluwer Academic Publishers, Boston, 1993.